

Worldsmart configuration Guide for SPA-941/942

Step 1: Obtain the IP-Address of SPA-941



Click on **Setup** on the Phone and choose 9th option "Network" there it will display the IP address of the phone saying "Current IP"

Step 2: Access the web configuration page for SPA-941/942


- Obtain the IP-Address-of-SPA-941/942
- Open the browser and give the following URL (<http://IP-Address-of-SPA-941>), this brings up the web configuration page.

A screenshot of the Linksys Telephone Configuration web page. The page has a dark blue header with the Linksys logo and 'A Division of Cisco Systems, Inc.' on the left, and 'Linksys Telephone Configuration' on the right. Below the header is a navigation bar with 'Info', 'System', and 'User' tabs. On the right side of the navigation bar, there are links for 'Admin Login', 'basic', 'advanced', 'Personal Directory', and 'Call History'.



Click the Link “**Advanced**” on the web configuration page displayed

Now, click on “**Admin login**” on the web configuration page.



Click on the tab “**Ext 1**” and **Set the following parameters and save:**

Call Feature Settings

Message Waiting : **yes**
Voice Mail Server : **extension-accountname@p8.wspbx.com**

Proxy and Registration

Proxy: **p8.wspbx.com**
Use Outbound Proxy: **yes**
Outbound Proxy: **p8.wspbx.com**
Register Expires : **120**
Register : **yes**
Proxy Fallback Int : **3600**

Subscriber Information

Display Name: **support**(This is the caller id)
User ID: **username1-accountname**
Password: **userpassword**(Worldsmart login password)
Use Auth ID: **yes**
Auth ID : **username1-accountname@ p8.wspbx.com**

Audio Configurations

Preferred Codec : **G729a**
Use Pref Codec Only: **No**
G729a Enable: **Yes**



Call Feature Settings

Blind Attn-Xfer Enable:	<input type="text" value="no"/>	MOH Server:	<input type="text"/>
Message Waiting:	<input type="text" value="no"/>	Auth Page:	<input type="text" value="no"/>
Default Ring:	<input type="text" value="1"/>	Auth Page Realm:	<input type="text"/>
Conference Bridge URL:	<input type="text"/>	Auth Page Password:	<input type="text"/>
Mailbox ID:	<input type="text"/>	Voice Mail Server:	<input type="text"/>
State Agent:	<input type="text"/>	CFWD Notify Serv:	<input type="text" value="no"/>
CFWD Notifier:	<input type="text"/>		

Proxy and Registration

Proxy:	<input type="text" value="p7.wspbx.com"/>	Use Outbound Proxy:	<input type="text" value="yes"/>
Outbound Proxy:	<input type="text" value="p7.wspbx.com"/>	Use OB Proxy In Dialog:	<input type="text" value="yes"/>
Register:	<input type="text" value="yes"/>	Make Call Without Reg:	<input type="text" value="no"/>
Register Expires:	<input type="text" value="120"/>	Ans Call Without Reg:	<input type="text" value="no"/>
Use DNS SRV:	<input type="text" value="no"/>	DNS SRV Auto Prefix:	<input type="text" value="no"/>
Proxy Fallback Intvl:	<input type="text" value="3600"/>	Proxy Redundancy Method:	<input type="text" value="Normal"/>

Subscriber Information

Display Name:	<input type="text" value="support"/>	User ID:	<input type="text" value="test-smarttest-com"/>
Password:	<input type="text" value="*****"/>	Use Auth ID:	<input type="text" value="no"/>
Auth ID:	<input type="text" value="test-smarttest-com"/>		
Mini Certificate:	<input type="text"/>		
SRTP Private Key:	<input type="text"/>		

Audio Configuration

Preferred Codec:	<input type="text" value="G729a"/>	Use Pref Codec Only:	<input type="text" value="no"/>
G729a Enable:	<input type="text" value="yes"/>	G723 Enable:	<input type="text" value="yes"/>
G726-16 Enable:	<input type="text" value="yes"/>	G726-24 Enable:	<input type="text" value="yes"/>
G726-32 Enable:	<input type="text" value="yes"/>	G726-40 Enable:	<input type="text" value="yes"/>
Release Unused Codec:	<input type="text" value="yes"/>	DTMF Process AVT:	<input type="text" value="yes"/>

Click on the tab “**Phone**” and look for Voice Mail Number and enter “mwi-ext”

LINKSYS
A Division of Cisco Systems, Inc.

Linksys Telephone Configuration

Info System SIP Provisioning Regional **Phone** Ext 1 Ext 2 User

User Login basic | advanced
Personal Directory Call History

General

Station Name:	<input type="text"/>	Voice Mail Number:	<input type="text" value="mwi-9000"/>
Text Logo:	<input type="text"/>		

Line Key 1

Extension:	<input type="text" value="1"/>	Short Name:	<input type="text" value="mwi-Extension"/>
Share Call Appearance:	<input type="text" value="private"/>		

Click on the tab “**SIP**”

RTP Parameters

RTP Port Min:	<input type="text" value="16384"/>	RTP Port Max:	<input type="text" value="16482"/>
RTP Packet Size:	<input type="text" value="0.020"/>	Max RTP ICMP Err:	<input type="text" value="0"/>
RTCP Tx Interval:	<input type="text" value="0"/>	No UDP Checksum:	<input type="text" value="no"/>
Symmetric RTP:	<input type="text" value="no"/>	Stats In BYE:	<input type="text" value="no"/>



Set the following parameter → RTP Packet size: 0.020